

## DURAFIRM ONE-METER STAND HARDWARE REPLACEMENT REQUIREMENTS

If you needs to replace all hardware for (1) Durafirm 1-Meter Stand

1. If the rail supports, fulcrum box and hinges have been disassembled, you will need these aluminum bolts:

(3) SF108  
(6) SF103  
(30) SF105  
(8) SF106

2. If the steps have been disassembled from the ladder, you will need:

Twenty-two (22) SF104

3. If the rail clamps and rail clamp bolts are missing, you will need:

(24) C207  
(24) SF118  
(2) C206

4. If the Durafirm diving "stand-to-deck" bolts are missing, you will need:

(8) SF127      Bolt  
(2) SF125      Bolt  
(8) SF138      (Washer)  
(4) SF139      (Washer)

5. If you need shims:

(1) MP108 square shim set

6. If you need the carriage bolts to bolt the diving board to stand:

(2) SF122

NOTE: This list DOES NOT include fulcrum or hinge parts, grease gun, grease or Touch-up paint.

The "buff" color touch up paint kit (which should be used to coat any stand bolts to seal out water) is Item MP105.