

DURAFIRM THREE-METER STAND HARDWARE REPLACEMENT REQUIREMENTS

To replace all hardware for a Durafirm 3-Meter Stand:

1. If the rail supports, fulcrum box, hinges have been disassembled, you will need these aluminum bolts:

(3) SF108
(6) SF103
(30) SF105
(8) SF106

2. If the steps have been disassembled from the ladder, you will need:

(38) SF104

3. If the rail clamps and rail clamp bolts are missing, you will need:

(26) C207
(26) SF118
(4) SF119
(2) C206

4. If the stand-to-deck bolts are missing, you will need:

(8) SF127 Bolt
(2) SF125 Bolt
(8) SF138 (Washer)
(4) SF139 (Washer)

5. If you need shims:

(1) MP108 square shim set

6. If you need the carriage bolts to bolt diving board to stand:

(2) SF122

NOTE: This list DOES NOT include fulcrum or hinge parts, grease gun, grease or Touch-up paint.

The "buff" color touch up paint kit (which should be used to coat any stand bolts to seal out water) is Item MP105.