

Durafirm Diving Stand Installation Hardware

DURAFIRM ONE-METER STAND INSTALLATION

If bolting to inserts:

- (4) SF124 5/8x 1 3/4" Bronze Hex-Head Bolts
- (4) SF125 5/8x 2" Bronze Hex-Head Bolts
- (4) SF127 5/8x 2 1/2" Bronze Hex-Head Bolts

You may also want to use the "Shims" that are packed with the install kit

and

- (12) SF138 5/8" Brass Washer
- (8) SF139 3/4" Brass Washer (ladder only)

IF BOLTING DURAFIRM STAND TO BRONZE ANCHORS:

- (4) SF125 5/8x 2" Bronze Hex-Head Bolts (These go where there are no shims)
- (4) SF127 5/8x 2 1/2" Bronze Hex-Head Bolts (Used beyond the 1/8" shim for water protection)

and

- (8) SF138 5/8" Brass Washer
- (4) SF139 3/4" Brass Washer (ladder only)

DURAFIRM "SHORT STAND" INSTALLATION:

Bolt to anchors:

- (6) SF127 Bolts
- (6) SF138 Washers

If bolting to inserts:

- (4) SF125 5/8x 2" Bronze Hex-Head Bolts
- (8) SF127 5/8x 2 1/2" Bronze Hex-Head Bolts

and

- (12) SF138 5/8" Brass Washers
- (8) SF139 3/4" Brass Washers (ladder only)

DURAFIRM THREE-METER STAND INSTALLATION:

If bolting to bronze anchors:

- (8) SF127 5/8x 2 21/2" Bronze Hex-Head Bolts
- (8) SF138 5/8" Brass Washers
- (4) SF139 3/4" Brass Washers

Different size bolts are used for leveling. There are plenty of room in anchors, thus less selection. The concrete inserts are shorter.

Three-Meter and One-Meter Stands have DIFFERENT SIZE bolts because of different FOOT CASING thickness.