

Installation Supplement Guard Rail Instructions

Guard rail support should be installed on the fulcrum unit matching coded arms with coded corners of fulcrum box, i.e. corner "A" with arm "A" etc.

A short tube with stainless steel rail clamps installed shows the method of assembly of guard rails. When slipping the rail clamps on the tubing, use care to prevent scratching. This can be accomplished by squeezing the rail clamps to a "round" shape while sliding them on the rail.

The curved rail tube is excessive in length on the ladder socket end. This is necessary for varying deck heights and slopes.

Carefully position tube in vertical supports and mark cut point at ladder socket, and cut the tube.

For stands with Double rails/both sides, the intermediate rail (at back) is connected to the curved rail clamps and bolts each.

When touching up bolts with touch-up kit, be sure to paint the rail clamp bolt heads.

After final assembly of rail support arms, remove all masking tape codes from arms and fulcrum box.