www.springboardsandmore.com

Phone 877.348.3246 Toll Free

HARDWARE NEEDED TO ATTACH GUARDRAILS TO DURAFIRM DIVING STANDS

The following is a list of what you will receive when ordering Durafirm Diving Stands WITH guardrails. This list will also advise you what small parts you will need to order if you plan to attach guardrails to your Durafirm Diving Stands or if you need to replace any guardrail hardware.

SS = "Short Stand"

SGR1S = Single Guardrails on ONE side

SGR2S = Single Guardrails on TWO sides

DGR2S = Double Guardrails on TWO sides

	SS	SS	SS	1 Meter	1 Meter	1 Meter	3 Meter
	SGR1S	SGR2S	DGR2S	SGR1S	SGR2S	DGR2S	DGR2S
		T	T	T		T	
SF105	12	22	22	12	22	22	22
SF106	5	10	2	5	10	2	2
SF110	12	22	22	12	22	22	22
SF117	4	6	10	4	4	6	6
SF118	8	14	18	8	14	18	18
SF119	2	4	12	2	4	12	12
SF153	0	0	2	0	0	2	6
*SB404	0	0	2	0	0	0	0
C206	0	0	2	0	0	2	2
C207	8	14	26	8	14	26	26

SF105 3/8" x 1 1/4" Aluminum hex-head bolt with SF110 nut for bolting rail supports to fulcru box. 3/8" x 1 1/2" Aluminum hex-head bolt with SF110 nut for bolting rail supports to fulcru	
00X. 3/8" x 1 1/2" Aluminum hey-head holt with SE110 nut for holting rail supports to fulcru	n
3/8" x 1 1/2" Aluminum hex-head bolt with SF110 nut for bolting rail supports to fulcru	n
box.	
SF110 Not sold separately they come with bolts	
SF117 5/16" x 1/2" Stainless Steel Rail Clamp Bolt	-
SF118 5/16" x 5/8" Stainless Steel Rail Clamp Bolt	-
SF119 5/16" x 3/4" Stainless Steel Rail Clamp Bolt	
SF153 5/16" x 7/8" Stainless Steel Rail Clamp Bolt - used only on Stands with DGR2S	
*SB404 Left or Right Painted Aluminum Rail Bracket. These attach to back of "Short Stand" a	nd are
used to hold the guardrails to the back of the "Short Stand."	
C206 Bronze Rail Bracket for 1M and 3M - You must also order separately (2) C207 and (2)
SF118 to attach the guardrails to the Bronze Rail Bracket.	
Stainless Steel Rail Clamp Attaches the guardrail to the rail support castings ("arms	") of
the Durafirm Stand.	

NOTES:

Most of the bolts listed above are painted. Recommend touch-up paint to coat nuts and threads after installation. (Item # MP105)

The reason you must sometimes use different bolt lengths is that some of the rail support castings are thicker than others. If the bolt is too long, you cannot properly tighten it.

The SB404's are NOT in the hardware box -- rather, they are attached to the stand itself. If you already have a "Short Stand" and plan to add guardrails to it, you must order the SB404's separately in order to attach the guardrails to the stand.