



MAINTENANCE OF DURAFLEX STANDS

Hose off the entire stand with fresh water each day of use. For Indoor pools, hose off the stand with fresh water EVERY DAY. The stand cools off at night, and warm humid air will condense on the stand and hand rails, leaving a corrosive chlorine residue on the equipment.

Keep the fulcrum components clean, especially the tracks.

Keep the roller clamp lock nuts, and anti-rattle lock nuts, snug and adjusted for a “no-rattle” clearance.

The two grease fittings of the roller block should be lubricated periodically. Use “Mystic JT-6” grease and grease gun.

The hinges that hold the board to the stand need 2 drops of oil every 2 weeks. Use lightweight oil as for door hinges.

Handrails: “304 stainless steel” is not rust-proof. Clean with stainless steel cleaner and a cloth if rust appears. Rinse with large amounts of fresh water (not pool water).

Check installation and board bolts for tension. Maintain to 110 ft lbs of torque.

Tighten rail clamp bolts periodically.

Maintain slip-resistant step inserts with the same procedure as the diving board.

P-121 (Revised 5/2017)